


Sym	Revisions	Date	By

Clean both the 4" OD and the 6" ID. Place the gasket on the end of the 4" house pipe with the white stripe facing the end of the pipe. Push the 6" pipe over the gasket, one complete revolution until it "locks" into place. No lube, no water, just push the joint together.

Typical Installation of the Vertite 4 to 6 O-D Gasket.

08-19-03

		Elastomeric Seals	
Mogadore OH 44260 USA			
Description			
VERTITE O-D 4" to 6"			
Material			
C425, C443, C923, 40±5			
Scale	Date	Drawn By	Die Number
Note	12-28-00	WCA	V-0050